

## ClampFast Fitting Instructions



Tools required: 4mm Allen key, 8mm spanner

Decide on the placement of the mount on the roll cage. Loosely secure using the bolts and lock nuts. Tighten these evenly on each side until it is hard to move the clamp. The fixings only need to be tightened to 1 or 2Nm which is not much! Tightening the bolts any more risks breaking the clamp so take it easy!

The camera clamps are designed to be tight fit. You can open up the clamp by carefully easing a flat-bladed wide screwdriver into the slot. Fit the cameras into the correct size clamp. The number on the clamp is the size in mm.

20mm is for the VBOX Lite low-resolution camera, 21mm for the Lite high-resolution camera and 24mm for VBOX HD2 cameras.

Tighten the camera clamp bolts and lock nuts. These fixings only need to be done up tight enough so that the cameras do not easily rotate.

## RaceSense



We have also produced add-on electronics for video loggers e.g. VBOX to measure RPM, throttle, acceleration and rotation.

You can use this to check your driving inputs and improve your speed on track. Initially for Caterham models this is an easy to fit kit.

The extra signals can be easily added to VBOX™ scenes and viewed as graphs in CircuitTools™. Example scenes, instructions and support provided.